

```
/*A basic 4 channel transmitter using the nRF24L01 module.*/
```

```
#include <SPI.h>
#include <nRF24L01.h>
#include <RF24.h>
```

```
/*Create a unique pipe out. The receiver has to wear the same unique code*/
```

```
const uint64_t pipeOut = 0xE8E8F0F0E1LL;
//IMPORTANT: The same as in the receiver
```

```
RF24 radio(9, 10); // select CSN pin
```

```
// The sizeof this struct should not exceed 32 bytes
// This gives us up to 32 8 bits channels
```

```
struct MyData {
    byte throttle;
    byte yaw;
    byte pitch;
    byte roll;
    byte AUX1;
    byte AUX2;
};
```

```
MyData data;
```

```
void resetData()
{
    //This are the start values of each channel
    // Throttle is 0 in order to stop the motors
    //127 is the middle value of the 10ADC.

    data.throttle = 0;
    data.yaw = 127;
    data.pitch = 127;
    data.roll = 127;
    data.AUX1 = 0;
    data.AUX2 = 0;
}
```

```
void setup()
{
    //Start everything up
    radio.begin();
    radio.setAutoAck(false);
    radio.setDataRate(RF24_250KBPS);
    radio.openWritingPipe(pipeOut);
    resetData();
}
```

```
/******
```

```
// Returns a corrected value for a joystick
position that takes into account
```

// the values of the outer extents and the middle of the joystick range.

```
int mapJoystickValues(int val, int lower, int middle, int upper, bool reverse)
```

```
{
```

```
    val = constrain(val, lower, upper);
```

```
    if ( val < middle )
```

```
        val = map(val, lower, middle, 0, 128);
```

```
    else
```

```
        val = map(val, middle, upper, 128, 255);
```

```
    return ( reverse ? 255 - val : val );
```

```
}
```

```
void loop()
```

```
{
```

```
    // The calibration numbers used here should be measured
```

```
    // for your joysticks till they send the correct values.
```

```
    data.throttle = mapJoystickValues(
analogRead(A4), 0, 521, 1023, true ); //Change to A4 for potentiometer controlled
```

```
    data.yaw      = mapJoystickValues(
analogRead(A1), 0, 535, 1023, false ); //525
```

```
    data.pitch    = mapJoystickValues(
analogRead(A2), 0, 501, 1023, true ); //511
```

```
    data.roll     = mapJoystickValues(
analogRead(A3), 0, 512, 1023, false ); //502
```

```
data.AUX1      = digitalRead(2); //The 2 toggle  
switches  
data.AUX2      = digitalRead(3);  
  
radio.write(&data, sizeof(MyData));  
}
```